

Precision Viewer 17" -Excellence Series-

ENGLISH

PRECISION VIEWER 17" – EXCELLENCE SERIES –

User's manual

Version 1.0

NEDERLANDS

Thank you

Thank you very much for purchasing this product from the Trust range. We wish you hours of fun with it. Please read this manual carefully before using the product.

Registration

Register your purchase now at the Trust Internet site (www.trust.com) and you could win one of the fabulous prizes. The web site is also the place to look for dealer addresses, comprehensive product information, drivers, and FAQ (Frequently Asked Questions) sheets.

Copyright Statement

No part of this manual may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's personal use, without the prior written permission of the manufacturer.

Disclaimer Statement


The manufacturer specifically disclaims all warranties, either express or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to the software, the product manual(s) and written materials, and any other accompanying hardware. The manufacturer reserves the right to revise or make improvements to its product at any time and without obligation to notify any person of such revisions or improvements.

In no event shall the manufacturer be liable for any consequential or incidental damages, including any loss of business profits or any other commercial damages, arising out of the use of its product.

* All company or product names are trademarks or registered trademarks or service marks of their respective owners.

Contents

1. Introduction	2
2. Safety	2
3. Installing the monitor	3
3.1 Unpacking	3
3.2 Fastening the swivel-and-tilt base	3
3.3 Positioning the monitor	4
3.4 Connecting the monitor	4
4. Installing the driver	5
4.1 Windows 95 / 98.....	5
4.2 Other operating systems	6
4.3 Setting the refresh rate.....	6
5. Operation	7
5.1 Control buttons on the monitor	7
5.2 OSD menu.....	7
5.3 Power saving	9
6. Troubleshooting	11
7. Specifications	14
8. Warranty	15
8.1 Service	15
8.2 Conditions	15
8.3 Service Centres	16



1. Introduction

This manual contains instructions for installing and operating the Precision Viewer 17" -Excellence Series. No prior knowledge is required for the installation and operation.

This monitor is suitable for professional use in an office environment. The Precision Viewer 17" -Excellence Series- is versatile, ergonomic and easy to use.

Conventions

The following layout conventions are used in this manual:

'System' Program term, which is visible on the screen.

[data] Text is entered between the brackets.

Important information is shown as follows:

Note: *Do not leave the equipment out in the rain.*

Minimum system requirements

- A computer with a standard VGA signal.

2. Safety

Read the following carefully before use:

1. Do not use this equipment in humid environments like bathrooms, damp cellars, swimming pools, etc.
2. Never insert objects into the openings on the outside of the device as you can come into contact with live electrical components. This can cause fire or give strong electrical shocks.
3. Do not try to repair the equipment yourself.
4. You should disconnect the power supply and have the equipment repaired by qualified personnel if:
 - a) the cable or the plug is damaged or worn;
 - b) the equipment has come into contact with fluids;
 - c) the equipment is not functioning properly;
 - d) the equipment has been dropped and/or the casing has been damaged.

3. Installing the monitor

3.1 Unpacking

The following items should be found in the packaging:

- Monitor
- Swivel-and-tilt base
- Mains cord
- This manual

Please contact your dealer if anything is missing or damaged.

Tip: Save the box for future transportation.

3.2 Fastening the swivel-and-tilt base




Figure 1: Fastening the base

Follow the instructions below to fasten the base:

1. Place the base against the bottom of the monitor so that the base fasteners are aligned with the appropriate slots. See Figure 1.
2. Push the base towards the front of the monitor until the latch locks into position. See Figure 1.

The base is now bolted in place. See section 3.3 for positioning the monitor.

3.3 Positioning the monitor

1. Place the monitor in a convenient location near your computer.
2. Position the monitor so that the top of the screen is no higher than eye level.
3. Position the monitor directly in front of you at a comfortable reading distance (around 45 to 60 cm).
4. Position the monitor so that you will not experience any problems with reflecting, etc.

3.4 Connecting the monitor




Figure 2: Connecting the monitor


Note: *This monitor can also be connected to an Apple Macintosh computer. Ask your dealer for a conversion cable.*

Follow the instructions below for connecting the monitor to your computer. See Figure 2.

1. Switch off the computer.
2. Insert the 15-pin signal cable connector (E) to the VGA connection (F) on your computer and screw it down.

3. Plug the mains cord connection (B) to connection (A) on the monitor.
4. Plug the other end of the mains cord (C) to your computer's mains supply connection (D).
5. Switch on the computer.

Note: *If your computer does not have a mains connection for a monitor, plug the monitor directly into the wall socket. Ask your dealer for a mains cord.*



4. Installing the driver

4.1 Windows 95 / 98

This monitor complies with Microsoft Window's Plug and Play standard. The monitor will be detected automatically when starting Windows 95 or 98.

1. Switch on the monitor.
2. Start Windows. New hardware will be found (Plug and Play monitor) and the 'Add New Hardware Wizard' will start up.
3. Click on 'Next' to continue. See Figure 3.



Figure 3: Installing the driver

4. Follow the on-screen instructions for installing the proper driver. Windows will locate the driver for the Plug and Play monitor.

The computer does not need to be restarted following installation.

4.2 Other operating systems

No drivers are required for other operating systems, such as DOS, Windows 3.1x or Windows NT.

The recommended setting is a resolution of 1024x768 and a refresh rate of 85Hz.

4.3 Setting the refresh rate

Follow the instructions below to set your refresh rate in Windows 98:

1. Go to the configuration window (Start - Settings - Configuration window).
2. Double-click on the 'Display' icon.
3. Click on the 'Settings' tab.
4. Click on the 'Advanced' button.
5. Click on 'Adapter' and select 85Hz from the list.
6. Click on 'Apply' to accept the selected value.

The installation is now complete. See chapter 5 for instructions on how to operate the monitor.

5. Operation

5.1 Control buttons on the monitor




Figure 4: Frontal view of the monitor

A	'ZOOM' button. Press this button and rotate the button (D) to enlarge or reduce the image.
B	'RECALL' button. This button has 2 functions, namely: <ol style="list-style-type: none"> 1. Switching off the OSD menu. 2. Retrieving the default settings.
C	'ONE TOUCH OSD' button. Press this button to obtain the OSD main menu and to select a function.
D	'ADJUST' button. Rotate this button to scroll through the OSD menu and to change the selected function.
E	'Power LED'. Displays the status of the monitor when lit.
F	'Soft Power' button. Push-button for switching the monitor on and off.

5.2 OSD menu

This monitor is equipped with an On Screen Display (OSD) for changing your monitor settings via the display screen.

Press the 'ONE TOUCH OSD' button (C) to obtain the OSD main menu. A menu like the one shown in Figure 5 will pop up.




Figure 5: OSD main menu








The OSD main menu is divided into 2 windows. The upper window displays the current resolution and refresh rate.

The second window displays all functions that can be changed. Use the turn knob (D) to scroll through the OSD menu and press the 'ONE TOUCH OSD' button (C) to select a function.

A new OSD window will appear for every function selected. Press the 'ONE TOUCH OSD' button in this window to select the function you wish to change. Use the turn knob (D) to adjust the value of the selected function.

See the table below for descriptions of the various functions.

Icon	Function	Description
	Contrast / Brightness	For adjusting the contrast and brightness.
	H-position / V-position	For adjusting the horizontal and vertical position of the display image.
	H-size / V-size	For adjusting the horizontal and vertical size of the display image.
	Pincushion / Trapezoid	For correcting pincushion and trapezoid distortion.
	Parallel / Pin Balance	For correcting parallel and pin balance distortion.

Icon	Function	Description
	Corner Pin / Rotation	For correcting angle deflection and a rotated display image.
	H-moire / V-moire	For readjusting the horizontal and vertical moire.
	Degauss	For demagnetising the display image.
	Color Control	For adjusting the RGB value (manually) or colour temperature (6550K, 9300K).
	Mode Information	For requesting the default settings and user settings.
	Language	For selecting a language (English, German, Italian, Spanish or French).
	OSD Display Time	For setting the amount of time that the OSD menu should be displayed (5, 8, 12, 20 or 30 seconds).
OSD	OSD Adjust	For setting the horizontal position, vertical position and size of the OSD display.
DPMS	DPMS Select	For selecting the power-saving mode (VESA or NUTEK). See section 5.3.

5.3 Power saving

This monitor complies with EPA (Environmental Protection Agency) and NUTEK standards. The power-saving feature is only effective if the monitor is connected to a computer that supports the VESA DPMS (Display Power Management Signalling). See the table below for the status of the monitor:

Status	Signal			Power Consumption	Refresh time	LED colour
	H-Sync.	V-Sync.	Video			
On	Pulse	Pulse	Active	90 Watt	-	Green
Stand-by	No pulse	Pulse	Black screen	60 Watt	<1 sec.	Flashing green/yellow (OSD select)
				15 Watt	<3 sec.	
Suspend	Pulses	No pulse	Black screen	<15 Watt	<3 sec.	Flashing green/yellow

Precision Viewer 17" -Excellence Series-

Status	Signal			Power Consumption	Refresh time	LED colour
	H-Sync.	V-Sync.	Video			
Off	No pulse	No pulse	Black screen	<5 Watt	<15 sec.	Yellow

6. Troubleshooting

If your monitor is not functioning properly, you may be able to solve the problem by locating the problem and possible solution in the following table.

Problem	Cause	Possible solution
No display image, LED is not lit.	Monitor is not switched on.	Switch on the monitor. See section 5.1.
	Mains cord is not connected.	Connect the mains cord. See section 3.4.
No display image, but LED is lit.	Computer is switched off or 'hanging'.	Switch on the computer or reset it by switching it off and then on again.
	Computer is in the 'power-saving' mode.	Move the mouse or press a key.
	A so-called 'screensaver' has been activated.	Move the mouse or press a key.
	The signal cable is not connected.	Connect the signal cable. See section 3.4.
	Contrast and/or brightness is set improperly	Adjust the contrast and/or brightness. See section 5.2.
Announcement on screen: 'out of range'.	The computer is sending a signal that the monitor does not support.	Lower the resolution or refresh rate. See section 4.3.
There is a coloured spot in the display image or the colours are faded.	There is a loudspeaker or magnet next to the monitor.	Remove the loudspeaker or magnet. Try the monitor at a different workplace. Select the 'Degauss' function from the OSD menu. See section 5.2.
	The monitor has been rotated or moved after being switched on.	Select the 'Degauss' function from the OSD menu. See section 5.2.

Problem	Cause	Possible solution
The picture is bouncing or a wave pattern is present in the display.	There is a device with a transformer or adapter nearby (such as a TV, radio or loudspeaker).	Remove or move the source of disturbance. Try the monitor at a different workplace if necessary.
The colours are faded or lacking.	The signal plug is not properly secured in the computer.	Secure the plug. See section 3.4.
	Defective VGA card.	If possible, try the monitor with a different computer in order to check whether it works.
	Pin 1, 2 or 3 on the signal plug is bent or broken.	Straighten the pin. Note: the pins break off very easily (and do not fall under the guarantee)
Display image is not centred.	Position settings set improperly.	Adjust the horizontal position (H.Position) and vertical position (V.Position). See section 5.2.
Display image is too small or too large	Size settings set improperly.	Adjust the horizontal size (H.size) and vertical size (V.Size). See section 5.2.
Display image is too dark or too light	Contrast and brightness settings set improperly.	Adjust the contrast and brightness (section 5.2).
Display image is in the form of a trapezoid. Example: / \ or \ /.	Trapezoid setting set improperly.	Adjust the trapezoid setting. See section 5.2.
Display image is convex or concave.	Pincushion setting set improperly.	Adjust the pincushion setting. See section 5.2.
Display image is tilted.	Rotation setting set improperly.	Adjust the rotation setting. See section 5.2.

Problem	Cause	Possible solution
Windows Plug and Play does not recognise the monitor.	Pins in the signal plug are bent.	Straighten the bent pins. Note: the pins break off very easily (and do not fall under the guarantee)
	Defective VGA card.	Try the monitor with a different computer.
There is a moiré pattern on the image (blurred strips or circular lines that do not belong in the image).	The OSD menu's moiré pattern setting has been changed too quickly.	For some models, the moiré pattern can be adjusted using the OSD menu. When using the OSD menu, do not change the value too quickly. Slowly change the value because every value can reduce or remove the effect.

Monitor self-test:

This monitor is capable of checking the input signal. Whenever the signal cable is disconnected or if no signal is detected, the monitor will switch to the 'AUTO POWER OFF MODE'. An OSD announcement will appear and the monitor will switch off.

If the 'ONE TOUCH OSD' button (C) is now pressed, an RGB test pattern will appear on the screen. There is nothing defective about the monitor if this screen appears. Check the signal cable and your computer.

If the signal falls outside the range of the monitor, the announcement 'OUT OF RANGE' will appear on the screen. The horizontal and vertical frequency of this signal will also be displayed. The wrong frequency will flash. Check your system or switch to a different resolution.

If these suggestions are not of any help, consult the Trust Internet site at www.trust.com. Please contact your dealer if you still have problems after you have tried these solutions. You should keep the following information available:

- Brand name and type of monitor;
- Brand name and type of computer;
- Operating system language and version;
- Resolution being used;
- Refresh rate being used;
- Exact description of the problem.

7. Specifications

Screen size	17 inch
Viewable size	16 inch (40.5 cm)
Dot pitch	0.27 mm
Display area	330 x 245 mm
Number of colours	Infinite
Maximum resolution	1280x1024 non interlaced
Horizontal synchronisation	30 to 70 KHz
Vertical synchronisation	50 to 150 Hz
Bandwidth	108 MHz
Video mode recognition	Automatic
Plug and Play	DDC 1 / 2B (Display Data Channel)
Voltage	100-240 V AC, 50/60 Hz
Power consumption	90 Watt
Dimensions (HxWxD)	416 x 416 x 447 mm
Weight	16 Kg
Operating temperature	0° C - 40° C
Compliance	UL, CSA, DHHS, N, D, FI, S, CE, FCC-B, VESA DPMS, NUTEK A, EPA, TÜV-GS, ISO-9241-3, TCO99.

8. Warranty

8.1 Service

- On-site service for the first year in the following countries: Belgium, Denmark, France, Germany, Italy, Luxembourg, the Netherlands, Norway, Spain, Sweden and the United Kingdom. This means that you contact your national service centre (mentioned elsewhere in this manual) whereupon the faulty product will be exchanged at your own door.
- The second and third year of the warranty involves a 'carry-in service'. You send the faulty product to your national service centre. If there is no service centre in your country, then you can send the product to the nearest service centre in a neighbouring country. The only cost you are required to pay is the postal cost to send the product to the service centre. The product will be delivered to your door free of charge after repair.
- For all European countries not mentioned above, the warranty condition for the first year is the 'carry-in' service instead of on-site and is therefore the same as the second and third years.
- If your monitor may be faulty, always check the following before contacting our service centre:
 - Read and check the 'Troubleshooting' chapter
 - If possible, check the FAQs on our website: www.trust.com
 - Read the warranty conditions
- Make sure you have the following information available when you contact our service centre:
 - **Proof of purchase** which includes the date of purchase (**this is also a proof of warranty, so keep it in a safe place**)
 - The product's article number (1xxx), the product name and type
 - The serial number
(Please be aware that you may be required to wait for a longer period of time if you phone between 12:00 AM and 2:00 PM.)
- Make sure that you do not send accessories with your monitor, such as cables or the manual. The monitor support can remain attached to your monitor.

8.2 Conditions

- The on-site service consists of the following: If you call our service centre before 13:00 on a working day, the product will be exchanged no later than the following working day in 90% of cases (24 hour service). The reaction time may be longer due to local accessibility, journey distance, transport over water and holidays.
- Trust® Computer Products warrants to the original purchaser of this product, purchased from the authorised resellers or distributors, that it will be free from defects in material and workmanship for a period of 36 months from the date of purchase (excluding consumable and accessory items such as power cords and

cables, manual and cosmetic items which do not affect the normal operation of the product).

- Warranty service is available to the original purchaser by delivering the product during the warranty period to the available service centres.
- Proof of purchase must be provided showing the purchase date, product serial number and the seller's and buyer's names.
- The purchaser shall bear all shipping, packing, insurance costs and all other costs, excluding labour and parts which are necessary to repair, replace or return under this warranty.
- The service centre will invoice the purchaser all labour, parts and transportation costs in case of no fault found, mechanical damage (like damaged housing, PCB, CRT, cables, connectors or controls), mistreatment of the product and/or opened/repared by an unauthorised service person.
- You can also read the general conditions of the warranty on our website: www.trust.com. Contact your nearest service centre for the service conditions that apply for you.

8.3 Service Centres

Country:	Contact:
UK	Eurographic Industries Ltd E-mail mark@eurographics.co.uk Mail Unit 6 Premier Way Abbey Park Industrial Estate Romsey Hampshire SO51 9AQ United Kingdom Fax +44-1794-830044 Phone +44-1794-830775
Italy	Sirpel E-mail r.ballada@sirpel.it Mail 10090 S. Bernardo d'ivrea Via Cuneo - Zona Industriale PiP Italy Fax +39-125-632085 Phone +39-125-239954
France	Serrib E-mail p.guyot@serrib.com Mail 25 Rue Albert Camus BP 355 F-90006 Belfort Cedex France Fax +33-84-545554 Phone +33-3-84545519

Country:	Contact:
Benelux	<p>NGP E-mail paul@ngp.nl Mail Dwarsdijk 4 5705 DM HELMOND The Netherlands Fax +31-4925-23781 Phone +31-4925-22466</p>
Germany	<p>M+S Internet www.repair-center.de E-mail fleckenb@mus.de Mail Nordring 55-57 63843 NIEDERNBERG Germany Fax +49-60-28944211 Phone +49-60-28944212</p>
Spain	<p>Seltron S.L E-mail jose_luis@jet.es Mail C/Industria,44-46 08830 Sant Boi De Llobregat Barcelona Spain Fax +34-936-308104 Phone +34-936-529772</p>
Sweden	<p>Ibas Laboratories Internet www.ibas.se E-mail ibas@ibas.se Mail Bergkaellavaegen 32 191 30 Sollentuna/Stockholm Sweden Fax +46-8-6267608 Phone +46-8-6267600</p>
Norway	<p>Ibas Laboratories A/S Internet www.ibas.no E-mail leif.arne.melgaard@ibas.no Mail Industriveien 65 2200 Kongsvinger Norway Fax +47-628-10150 Phone +47-628-10100</p>
Denmark	<p>Ibas Laboratories A/S Internet www.ibas.dk E-mail ibas@ibas.dk Mail Ved Klaedebo 12 2970 Hoersholm Denmark Fax +45-45-760121 Phone +45-45-760110</p>