

Trust Padfighter 200 Plus

User's Manual

Copyright Statement

No part of this manual may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's personal use, without the prior written permission of the manufacturer.

Disclaimer Statement

The manufacturer specifically disclaims all warranties, either express or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to the software, the product manual(s) and written materials, and any other accompanying hardware. The manufacturer reserves the right to revise or make improvements to its product at any time and without obligation to notify any person of such revisions or improvements.

In no event shall the manufacturer be liable for any consequential or incidental damages, including any loss of business profits or any other commercial damages, arising out of the use of its product.

* All company or product names are trademarks or registered trademarks or service marks of their respective owners.

Table of Contents

Introduction	4
Chapter 1 - Installation of the Gamepad	6
1.1 One gamepad.....	6
1.2 Two gamepads using a Y-connector	6
1.3 Centring your gamepad	7
1.4 Action Buttons.....	7
Chapter 2 - Troubleshooting	8
2.1 Problems and solutions	8
2.1.1 If your gamepad doesn't respond	8
2.1.2 The gamepad cursor cannot maintain its centre position or the cursor will not move in one direction.....	8
2.1.3 The button works in one program but not in another	8
2.2 Cleaning.....	9

Introduction

Thank you for purchasing the Trust Padfighter 200 Plus gamepad, which supports high-end game software on PC. This manual is a guide to the installation and use of the gamepad.

Chapter 1 explains how to install the Trust padfighter 200 Plus.

Chapter 2 gives solutions to problems.

Features & Benefits

- Compatible with any personal computer.
- The Trust Padfighter 200 Plus features several advanced ergonomic aspects that provide you with the most comfortable gamepad possible.
- For handheld use, the base is contoured to fit comfortably in the grasp of your hand.
- Positive-response fire buttons with turbo function will help you to win any game.
- The 2 meter cable length provides full operating space.
- High quality 15-pin connector to be firmly connected into your game port.

Compatibility

Hardware

- Personal computer equipped with a joystick port.

Note

Joystick ports are available on game cards and on enhanced sound cards.

Software

- Any gamepad/joystick-supported software written for your PC.

Chapter 1 - Installation of the Gamepad

1.1 One gamepad

1. Turn off the power to your computer.
2. Plug the Trust Padfighter 200 Plus connector into the 15-pin joystick port located on your game card or enhanced sound card. The Trust Padfighter 200 Plus can be plugged into either joystick Port A or Port B.
3. Turn the computer on and start your software program.
4. Select "Joystick" from the option menu.

1.2 Two gamepads using a Y-connector

1. Turn your computer off.
2. Attach the Trust Padfighter 200 Plus to one of the two joystick ends of the Y-connector.
3. Attach the second gamepad (or a joystick) to the other joystick connector of the Y-connector.
4. Attach the Y-connector plug into the 15-pin joystick port.
5. Turn the computer on and start your software program.
6. Select "2 Joysticks" from the option menu.

1.3 Centring your gamepad

1. Turn off your computer before you connect your gamepad to your computer, or your computer may not be able to detect it.
2. Before connecting your gamepad to your computer, make sure you have only one game port (15-pin female connector) or one game card with multiple game ports. Otherwise, your gamepad will not function properly. Should you have more than one game port, disable either one. You may need to consult your owners' manual or computer manufacturer for disabling procedures.
3. Unlike other pointing devices, The Trust Padfighter 200 Plus doesn't require driver software. As long as your game port functions properly, your gamepad should work automatically once you plug it in.
4. Certain games may require you to specify that you are using a gamepad as control device, and some games will have an option of centring the gamepad. Follow the instructions in your game manual for such installation or configuration procedures. If the object you want to control, moves to one direction when the direction buttons on the gamepad are in the central position, calibration of your game software might be the solution. Refer to the software manual for details.

1.4 Action Buttons

On the gamepad you will find four fire buttons, two normal fire buttons and two turbo fire buttons. In addition to these buttons, the gamepad has two extra buttons for advanced games. The extra buttons are functioning as "C" and "D" fire buttons and are located at the back of the gamepad. The exact function each fire button activates depends on your software program. Consult your software manual for a description of each fire button function. Some software programs utilize only one or two fire buttons.

Chapter 2 - Troubleshooting

2.1 Problems and solutions

2.1.1 *If your gamepad doesn't respond*

1. Make sure only one game port is enabled.
2. If you have a sound card with a joystick interface, disable it and use the connector already on the PC.
3. Check your sound card manual for instructions.
4. Check if you have a defective Y-connector.
5. If you are using an Y-connector with the Trust Padfighter 200 Plus, disconnect it and connect the gamepad directly to the game port.
6. Change the I/O address of the card that is conflicting with the game card, or remove this card.

2.1.2 *The gamepad cursor cannot maintain its centre position or the cursor will not move in one direction*

1. Make sure you have calibrated the Trust Padfighter 200 Plus for the game you are using.
2. Check if you have used another gamepad or joystick in your system prior to replacing it with Trust Padfighter 200 Plus. Your game might need recalibration then.

2.1.3 *The button works in one program but not in another*

1. Each time you switch games, the functions of the Trust Padfighter 200 Plus buttons may also change.
2. Refer to the game's instruction manual, learn how to assign functions.

2.2 Cleaning

1. Keep the Trust Padfighter 200 Plus free of dust by wiping the surface with a dry, soft cloth.
2. If the Trust Padfighter 200 Plus should require cleaning, wipe it with a cloth slightly dampened with clean water.
3. Never immerse the Trust Padfighter 200 Plus in any liquid.