


## 1. Safety

1. Disconnect the power plug from the main supply before cleaning the speaker set. Do not use liquid cleaners or aerosols. Wipe the speaker set with a moist cloth.
2. Do not use the speaker set near water.
3. Make sure nothing is placed on the power lead. Locate the speaker set so as to prevent damage to the power lead.
4. Do not insert any object whatsoever into the slots of the speaker cabinets.
5. Do not attempt to repair the speaker set yourself. The set should be serviced by qualified service personnel.

## 2. Connecting the speaker set



**Figure 1. Connecting the SoundWave 1000 3D Plus**

Connect the cables according to the diagram above. Use the "LINE OUT" output or the "SPEAK" (i.e. speaker) output of the sound card.

## 3. Use

1. Switch on the speakers. The power indicator will light up.
2. Set your computer to produce sound.
3. Adjust the sound with the controls provided:
  - Volume control (adjusts sound level)
  - Bass control (adjusts relative level of low frequencies)
  - 3D control (increases the stereo image of the sound)
4. A headphones connection is provided on the front panel.