

	Picture	Scanner	Computer	
<b>1</b>				
	<b>PC</b>		<b>Power on</b>	
<b>2</b>				
			<b>Windows</b>	
<b>3</b>				
			<b>Windows</b>	
<b>4</b>			<b>Connect</b>	

**5**

**6**

**7 Windows 2000+ME+98! ➡ 12**

**8**

Found New Hardware Wizard

Welcome to the Found New Hardware Wizard

This wizard helps you install software for:  
USB Scanner

If your hardware came with an installation CD or floppy disk, insert it now.

What do you want the wizard to do?

Install the software automatically (Recommended)

Install from a list or specific location (Advanced) 1

Click Next to continue.

< Back Next > Cancel 2

Found New Hardware Wizard

Please choose your search and installation options.

Search for the best driver in these locations.  
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.

Search removable media (floppy, CD-ROM...)

Include this location in the search: 1  
D:\WinXP Browse 2

Don't search. I will choose the driver to install.  
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.

< Back Next > Cancel

Windows XP

**9**

Browse For Folder

Select the folder that contains drivers for your hardware.

1  
WINNF (C:)  
Tr12920\_v3 (D:) 1

2  
ACROBAT  
Finereader  
Manual  
Tutorial  
Twain  
WinXP 2

To view any subfolders, click a plus sign above.

3  
OK Cancel 3

Found New Hardware Wizard

Please choose your search and installation options.

Search for the best driver in these locations.  
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.

Search removable media (floppy, CD-ROM...)


Include this location in the search:  
D:\WinXP Browse

Don't search. I will choose the driver to install.  
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.


< Back Next > Cancel

Windows XP

10




11






12



13



<b>14</b>		<b>Picture</b> 
<b>15</b>		<b>SCAN</b>
<b>16</b>		<b>SCAN</b>
<b>17</b>		<b>Computer</b> 
<b>18</b>	<b>FINISH</b>	