







<p>1</p>				
<p>2</p>			<p>INSTALL DRIVER WINDOWS XP, 2000, Me, 98SE</p>	
<p>3</p>				
<p>4</p>				

<p>5</p>		<p>INSTALL DRIVER WINDOWS XP, 2000, Me, 98SE +</p>
<p>6</p>	<p>Windows 2000, Me, 98SE ➡ 7</p> <p>Windows XP ➡ 8</p>	<p>FINISH DRIVER</p>
<p>7</p>		<p>WINDOWS 2000, Me, 98SE</p>
<p>8</p>		<p>CONFIG BT</p>


9			CONFIG BT
10			
11	<p>2X</p> 	OPEN ENTIRY BLUETOOTH NETWORK	

12

Windows XP:



Windows 98SE / Me / 2000:




2X


OPEN
ENTIRE
BLUETOOTH
NETWORK

13

Windows XP:



WINDOWS 2000, ME, 98SE



ENTIRE
BLUETOOTH
NETWORK

FINISH