

<h2>1</h2>		<p>Soundcard 2 channel 3.5mm → 2A.a Soundcard 5.1 channel 3.5 mm → 2B.a</p> <p>Portable CD player 3.5mm → 2A.b TV/VCR/DVD (2 channel) RCA → 2A.c DVD player (5.1 channel) RCA → 2B.b</p> <p>Output to speaker/amplifier → 3</p>	
<h2>2 A</h2>	<p>A = to soundcard B = to 3.5 mm Audio output (example Portable CD player) C = to stereo RCA Audio output (example TV)</p>		<p>STEREO INPUT</p>
<h2>2 B</h2>	<p>A = to 5.1 soundcard B = to DVD or 5.1 output amplifier</p>		<p>5.1 CHANNEL INPUT</p>
<h2>3</h2>		<p>5.1 Spk Out to speakerset or amplifier (not included; refer to user's manual speakerset or amplifier)</p>	<p>STEREO / 5.1 CHANNEL OUTPUT</p>
<h2>4</h2>		<p>1) Power on: LED Blue 2) Headphone: LED Blue</p>	