

Product information



- | | |
|---|---|
| A: Page-Up button: previous slide | H: Left mouse button: next slide |
| B: Laser pointer button | I: Connection button 2 |
| C: Right mouse button: select a specific slide | J: Battery compartment |
| D: On/Off button | K: Status LED |
| E: Optical track ball | L: Connection button 1 |
| F: Page-Down button: next slide | M: USB extension cable |
| G: Empty battery indicator | |

 The explanation of the slide functionality is based on Microsoft PowerPoint.

Installation

- 1 Turn on the PC and connect the USB receiver to a free USB port. If necessary, use the USB extension cable.
- 2 Windows 64 bit, Windows XP, Windows 2000 and Windows ME: the device is installed automatically.
- 3 Continue from step 13.
- 4 Windows 98 SE: continue from step 3.
- 3 Click "Next".
- 4 Click "Next".
- 5 Click "Next".
- 6 If this message is displayed, click "OK".
- 7 Insert the Windows 98 SE installation CD-ROM in your CD-ROM drive.
- 8 Click "Browse".
- 9 A: Select the "WIN98" folder on the Windows 98 SE installation CD-ROM.
B: Click "OK".
- 10 Click "OK".
- 11 Click "Finish".
- 12 If necessary, repeat steps 3 to 11.

Connecting

- 13 A: Insert the batteries.
B: Turn on the Presenter.
 - 14 A: Press connection button 1 on the USB receiver. The LED will go out.
B: Press connection button 2 on the Presenter. The LED on the USB receiver will be lit again.
- The Presenter is now ready for use.

Wireless performance

- Maximum wireless range: 20 metres.
- Metal objects close to or between the Presenter and the USB receiver can reduce the range.
- If necessary, use the USB extension cable to move the USB receiver to a different location.

**Energy**

- For the best performance, use rechargeable AAA NiMH batteries.
- The device will enter the energy saving mode when it is not used for 45 seconds. To save energy, turn the device off after use.

**Use**

- As a result of the 4,096 different IDs, it is possible to use more than one Presenter in the same room.

**Safety instructions**

- LASER CLASS II device. Never look directly at the laser beam!



- Never open or repair this device yourself.
- Do not use the device in a damp environment. Clean the device with a damp cloth.
- Do not recharge the batteries provided and do not throw them onto a fire.
- Observe the local regulations when disposing of the batteries.

Go to www.trust.com/14417 for up-to-date FAQs, drivers and instruction manuals.



- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14417/ce.

Wireless

- This class 1 wireless device works at a frequency of 2.4 GHz. It meets the essential requirements and other relevant conditions of R&TTE Directive 1999/5/EC and can be used in the following countries: all EU countries, as well as RU, TR, NO and HU. There are no limitations per channel for the above-mentioned countries. Go to www.trust.com/14417 for an updated list of the countries where the use of this device is permitted.
- There may be restrictions for the use of this device outside of the EU. If this device is used outside of the EU, check whether this device meets the local regulations. Frequency: 2,446 – 2,454 GHz. Bandwidth: 6-8 MHz, Power < 1 mW.
- Be careful when using wireless devices if you have a pacemaker or are dependent on other life-saving, sensitive electronic equipment, because this product transmits radio signals.

Warranty & copyright

- This device has a two-year product warranty which is valid from the date of purchase. Go to www.trust.com/warranty for more information.
- It is forbidden to reproduce any part of this instruction manual without the permission of Trust International B.V.