



User's manual

Version 1.0



UK

DE

FR

IT

ES

PL

NL

PT

GR

DK

SE

HU

CZ

SK


FI

NO

TR

RU

Speakers



Control Box



Standard Cables



F



G



H



I


Game Console & DVD Cables




J



K



2



3



4



5



X-BOX / PLAYSTATION

6



J

F



7

DVD Player




K


G




8



9



10



11

