

**Product information**

A: Speakers	E: Off / Speaker / Charge switch
B: Power contact pins	F: Power adapter connection
C: Foldable audio cable	G: Headphone connection
D: Charge indicator	H: Foldable stand

UK

**Charge battery**


- 1 Connect power adapter of PSP to power connection (F) and to mains.
- 2 Switch (E) in Charge position. Indicator (D) lits red.
- 3 When indicator (D) lits green: internal Li-ion battery fully charged. Disconnect power adapter.

**Use**

- 4 Insert PSP with downwards movement. Make sure power contact pins (B) are connected correctly and bulges fall in to place.
- 5 Pull cable (C) out and connect to audio input of PSP.
- 6 Switch (E) in speaker position. Charge indicator turns off.
- 7 Operate PSP. Use volume controls of PSP for sound adjustment.
- 8 Use stand (H) for comfortable viewing position. Push flap to remove PSP.

**Note****General use**

- Use only the original PSP power adapter. Unauthorized adapters may damage the product and PSP.
- Charge time is app. 8 hours when internal Li-Ion battery is completely depleted.
- Put switch (E) in Off position when not in use.
- If switch (E) is in speaker position, the internal battery will charge the PlayStation Portable to prolong playtime for max. 5 hours.
- For indicators or functions of PSP, please read PSP user's guide.
- The internal Li-ion battery of this product can not be taken out or replaced.

 **Safety instructions**

- Do not open or repair the device.
- Do not use the device in a damp environment. Clean the device with a dry cloth.

See [www.trust.com/14659](http://www.trust.com/14659) for up-to-date FAQs and instruction manuals.



- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at [www.trust.com/14659/ce](http://www.trust.com/14659/ce).



- If possible, dispose of the device at a recycling centre. Do not dispose of the device with the household waste.

**Warranty & copyright**

- This device has a two-year product warranty which is valid from the date of purchase. See [www.trust.com/warranty](http://www.trust.com/warranty) for more information.
- It is forbidden to reproduce any part of this instruction manual without the permission of Trust International B.V.