



Product information

A: Speakers	E: PSP support
B: Power indicator	F: On/Off switch
C: PSP audio connector	G: Battery compartment
D: PSP power connector	H: Power-in connection

UK


Use

- 1 Open battery compartment (G). Insert batteries.
- 2 Connect PSP to speaker set. Make sure connectors C and D are inserted completely.
- 3 Put switch (F) to ON. Indicator (B) lits blue.
- 4 Turn PSP on.
 PSP's own battery must have enough power.
- 5 Use volume controls of PSP for sound adjustment.
- 6 Connect power adapter of PSP to mains and to power connection (F) if batteries should not be used.
 PSP's own battery will be recharged, even if speaker set is ON or OFF.


Note**General use**

- Do not pick up the speaker set by the PSP support (E)! It is not made for that purpose.
- Use only the original PSP power adapter. Unauthorized adapters may damage the product and PSP.
- For specific PSP information, please read PSP user's guide.
- The PSP support (E) can be slightly different, depending of the model.

See www.trust.com/14738 for up-to-date FAQs and instruction manuals. For extensive service register at www.trust.com/register.

 **Energy**

- Batteries last app. 4 hrs. To save energy, turn speaker set off after use.
- Never recharge the batteries provided and never throw them onto a fire.
- If rechargeable batteries are used, they can not be charged with this product.
- Batteries will power only speaker set, not PSP.
- Observe local regulations when disposing of batteries.

 **Safety instructions**

- Do not open or repair this device.
- Do not use the device in a damp environment. Clean the device with a dry cloth.



- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14738/ce.



- If possible, dispose of the device at a recycling centre. Do not dispose of the device with the household waste.

Warranty & copyright

- This device has a two-year product warranty which is valid from the date of purchase. See www.trust.com/warranty for more information.
- It is forbidden to reproduce any part of this instruction manual without the permission of Trust International B.V.