

Product information

- A: Wall power connection (illustration: 2-pin EU version)
- B: Network cable connection
- C: Power indicator – Steady: connected to AC power
- D: Powerline indicator – Steady: another plug detected, Flashing: activity
- E: Ethernet indicator – Steady: PC (or other device) detected, Flashing: activity
- F: Network cable

UK

Start situation

- 1 At least one other Network Plug must already be available within your in-house power line!
 For internet facility: connect other Network Plug to LAN port of modem / router!

Connection

- 2 Turn PC on.
- 3 Connect cable (F) to PC.
- 4 Connect cable (F) to network plug.
- 5 Connect network plug to wall power outlet.
- 6 Repeat 2 – 5 to add more plugs to network (e.g. other PC's, game console, IPTV, etc.).

Installation PC software

- 7 Insert CD-ROM. Click Install software.
- 8 Follow on-screen instructions to finish.
- 9 Utility starts automatically.

Configuration (recommended)

- 10 (1) Click 'Security'. (2) Insert preferred network password. (3) Click 'Set Local'.
 (1) Click 'Advanced'. (2) Insert remote plug device password (see label). (3) Click 'Add'.
- 11 Remote plug must be present in network before 'Add' is pressed!
 Repeat to add all remote plugs available in your network!
 Passwords are case sensitive!
- 12 (1) Remote plug is added to local network. (2) Click 'Set All' to set private network password to all plugs. (3) Click 'OK'.

Note**Connecting and use**

- See the instruction manual included on the CD-ROM for details (only available in English).
- The illustrations show a 2-pins EU wall plug version. The 3-pins UK version operates the same way.
- For extended network use (e.g. file and printer sharing with different computers), basic network knowledge is required. If necessary, refer to 'Help' options of your computer.
- Depending on your network configuration, specific settings of devices involved may be needed. Refer to the User's Guide of those devices.
- For internet connection of game consoles via the Trust network plug, consult the User's Guide of your game console for the correct settings.

- Connect the product directly into the wall power outlet. Do not use (multiplug) extension cords or surge protectors.
- The electric wire range is max. 200 meter.
- This product is compatible with network plugs of different speed, however the total speed will be limited by the plug with lowest speed.
- The maximum theoretical network speed is 14 Mbps, but the real speed will depend on the quality of the power lines and on the amount of electric 'noise' on the power lines.

See www.trust.com/14811 for up-to-date FAQs, software and instruction manuals. For extensive service, register at www.trust.com/register.



Safety instructions

- Do not open or repair this device.
- Do not use the device in a damp environment. Clean the device with a dry cloth.
- If the device has been dropped or the casing is damaged, remove the plug from the wall socket and have the device repaired by qualified personnel:
- Leave a minimum of 20 mm free space around the device in order to ensure sufficient ventilation. The ventilation must not be obstructed by covering the ventilation openings with items such as newspapers, table cloths, curtains, etc.



- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14811/ce.



- If possible, dispose of the device at a recycling centre. Do not dispose of the device with the household waste.

Warranty & copyright

- This device has a two-year product warranty which is valid from the date of purchase. See www.trust.com/warranty for more information.
- It is forbidden to reproduce any part of this instruction manual without the permission of Trust International B.V.