





Product information

-  **A:** Wheel (scroll + tilt + 3rd button)
B: Left button
C: Right button
D: USB connection

Installation

- 1 (1) PC off. (2) Connect mouse. (3) PC on.
 Windows ME/2000/XP → 3
- 2 Press [Enter]. Follow on-screen instructions.
 Windows 98SE CD may be necessary.
- 3 Insert CD-ROM.
- 4 Click 'Install driver'. Follow on-screen instructions to finish.

Configuration

- 5 Double click icon.
- 6 (1) Click 'Wheel'. (2) Select 'Trust Mouse Mode'. (3) Click 'Apply'.
- 7 (1) Click 'Programmable button'. (2) Assign desired 3rd button function. (3) Click 'OK'.
 Click 'Help' for for function details.

Note

General use

- Adjust the speed of mouse pointer: (1) Open Windows Help (Start → Help). (2) Search "adjust the speed of mouse pointer". (3) Follow instructions.
- Some applications may need 'MS IntelliMouse compatible mode' for correct function (see 6).
- Use soft brush to clean the optical sensor when it is dusty.

See www.trust.com/14831 for up-to-date FAQs, drivers and instruction manuals. For extensive service, register at www.trust.com/register.

Safety instructions

- Do not open or repair this device.
- Do not use the device in a damp environment. Clean the device with a dry cloth.



- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14831/ce.



- If possible, dispose of the device at a recycling centre. Do not dispose of the device with the household waste.

Warranty & copyright

- This device has a two-year product warranty which is valid from the date of purchase. See www.trust.com/warranty for more information.
- It is forbidden to reproduce any part of this instruction manual without the permission of Trust International B.V.