



Product information

UK




- A:** Scroll-wheel and third button
- B:** Right button
- C:** Left button
- D:** Browser backward button
- E:** Browser forward button

Installation

- 1**  Computer off
- 2**  Connect USB


3



Computer on
Finish

Install Trust Easy Configuration Software

1



Computer on

2



Place CD in CD-ROM

3



Click "Install software"
Follow on screen instructions to finish

RemindersGeneral usage

Install Trust Easy Configuration software on CD to configure the 3rd, 4th and 5th button



Read the manual on CD for the use of the configuration program



Use soft cloth to clean the ball after a long time of use

UK

If you have any problems, go to www.trust.com/14849 for FAQ, drivers and manuals.

Safety

- Do not open or repair this device.
- Keep this device away from liquids, such as water.



- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14849/ce.



- If possible, dispose of the device at a recycling centre. Do not dispose of the device with the household waste.

Warranty & copyright

- This product has a two-year manufacturer's warranty which is effective from the date of purchase. For more information see www.trust.com/warranty
- Reproduction of this manual or any part of it is prohibited without permission from Trust International B.V.