





Comfortline Wireless Mini Mouse

1




2




Windows 7 → **3**

Vista / XP → **7**


3 **Windows 7**




4




5 sec.



5




6







Comfortline Wireless Mini Mouse


7 Vista / XP




8



9



10



11

