


Kids Headset



1



2



3



4

Windows 7/
VISTA




5

XP




9


5 Windows 7 / VISTA




6



7




8




Kids Headset


9 XP




10




11



12



13



14

