

Windows 8

Navigation icons: A (Start), B (System tray), C (Volume Mixer), D (Sound Control Panel).

System tray volume icon with icon B.

Open Volume Mixer dialog with icon C.

Sound Control Panel with icon D.

Microphone Properties dialog with icon E.

Windows 7/Vista

System tray volume icon with icon A.

Open Volume Mixer dialog with icon B.

Sound Control Panel with icon C.

Microphone Properties dialog with icon D.

Frequently Asked Questions

<http://www.trust.com/17028/faq>



Exis Chatpack

