





Quick Installation Guide

Urban Revolt bundle


1




2




3



4



5



6

Windows XP



Open Volume Control
Adjust Audio Properties



7

Sounds and Audio Devices Properties

Volume Sounds Audio **Voice** Hardware

Realtek AC97 Audio

Device volume

Low High

Mute

Place volume icon in the taskbar

Advanced...

Speaker settings

Use the settings below to change individual speaker volume and other settings.

Speaker Volume... Advanced...

OK Cancel Apply

8

Sounds and Audio Devices Properties

Volume Sounds Audio Voice **Hardware**

These settings control volume and advanced options for the voice playback or recording device you selected.

Voice playback

Default device: Realtek AC97 Audio

Volume... Advanced...

Voice recording

Default device: Realtek AC97 Audio

Volume... Advanced...

Test hardware...

OK Cancel Apply

9

Recording Control

Options Help

Properties **Advanced Controls** Exit

Line In Microphone

Balance: Volume: Select

Balance: Volume: Select

Balance: Volume: Select

Realtek AC97 Audio

10

Recording Control

Options Help

CD Player Line In Microphone

Balance: Volume: Select

Balance: Volume: Select

Balance: Volume: Select

Advanced

Realtek AC97 Audio

?

trust.com/17624/faq