





Quick Installation Guide

HELIOS Wireless solar keyboard



EN

- Sleep mode
- Volume +
- Mute
- Volume -
- Internet Browser

DE

- Sleep-Modus
- Volumen +
- Stummschaltung
- Volumen -
- Internetbrowser

IT

- Modalità sleep
- Volume +
- Mute
- Volume -
- Browser Internet

FR

- Mode veille
- Volume +
- Sourdine
- Volume -
- Navigateur Internet

NO

- Hvilemodus
- Volum +
- Demping
- Volum -
- Nettleser

ES

- Modo de reposo
- Volumen +
- Silencio
- Volumen -
- Navegador

PT

- Dormer modo
- Volume +
- Sem som
- Volume -
- Browser Internet






NL

- Slaap mode
- Volume +
- Dempen
- Volume -
- Internet browser






FI

- lepotilaan
- Tilavuus +
- Mykistys
- Tilavuus -
- Internet selain

DA

-  Sove mode
-  Volumen +
-  Dæmp
-  Volumen -
-  Internetbrowser






HR

-  Stanje mirovanja
-  Glasnoća +
-  Prigušeno
-  Glasnoća -
-  Pretraživač Interneta






SE

-  Sova mode
-  Volym +
-  Tyst
-  Volym -
-  Webbläsare






CZ

-  Spat Způsob
-  Objem +
-  Ztlumit
-  Objem -
-  Spustit internetový prohlížeč






HU

-  Alvó üzemmód
-  Térfogat +
-  Elnémítás
-  Térfogat -
-  Webböngésző






BG

-  Режим на съня
-  Обемът +
-  Изключване на звука
-  Обемът -
-  Интернет браузър






SI

-  Način spanja
-  Glasnost +
-  Nemo
-  Glasnost -
-  Internetni brskalnik






RS

-  Stanje pripravnosti
-  Jačina zvuka +
-  Prigušeno
-  Jačina zvuka -
-  Internet pretraživač






TR

-  Uyumak modu
-  Ses +
-  Sessiz
-  Ses -
-  Internet Tarayıcısını






SK

-  Spať Spôsob
-  Objem +
-  Stlmenie zvuku
-  Objem -
-  Internetového prehľadávača






RO

-  Mod de somn
-  Volum +
-  Mute
-  Volum -
-  Motorul de căutare internet






RU

-  Режим сна
-  Объем +
-  Без звука
-  Объем -
-  браузерa

PL

-  Tryb uśpienia
-  Wielkość +
-  Wyciszenie
-  Wielkość -
-  Przeglądarki Internetu

EL

-  νάρκης
-  Όγκος +
-  Αποκοπή
-  Όγκος -
-  Άνοιγμα προγράμματος περιήγησης στο διαδίκτυο

Frequently asked questions

www.trust.com/18422/faq