



4. CONNECTING DEVICES



*not included


5. ECO MODE



FAQ

EN: Battery inside. Use and transport it in an upward position.
 DE: Akku im Inneren. In aufrechter Position bei Nutzung und Transport.
 IT : Batteria all'interno. Usare e trasportare in posizione verticale.
 ES: Baterías en el interior. Utilizar y transportar en posición vertical.
 FR: Batteries à l'intérieur. Utiliser et transporter en position vertical.
 NL: Batterij binnenin. Naar boven toe richten bij gebruik en vervoer.

Frequently asked questions <http://www.trust.com/21216/faq>




Trust
URBAN




USER GUIDE
— FIESTA PRO —


1. CHARGING




2. WIRELESS SETUP 1/2



3. WIRELESS SETUP 2/2



4. WIRELESS TROUBLESHOOTING



5. WIRELESS PLAYBACK

