


3. LIGHT MODE



PRESS 1X



MODE1/MODE2:	MUSIC
MODE3/MODE6:	PATTERN
MODE7:	RANDOM
MODE8:	OFF

FAQ

FREQUENTLY ASKED QUESTIONS

[HTTP://WWW.TRUST.COM/21760/FAQ](http://www.trust.com/21760/faq)


Trust
URBAN




USER GUIDE
WIRELESS SPEAKER

DIXXO

1. CHARGING



2A. WIRELESS - SETUP



2B. WIRELESS SETUP

