




6.



- OPTIONS**  
 LEFT CLICK  
 RIGHT CLICK  
 MIDDLE CLICK  
 FORWARD  
 BACKWARD  
 FIRE KEY  
 TRIPLE CLICK  
 DPI +  
 DPI -  
 DPI LOOP  
 PLAY / PAUSE  
 NEXT  
 PREVIOUS  
 VOLUME +  
 VOLUME -  
 STOP  
 MUTE  
 COPY  
 CUT  
 PASTE  
 DEKSTOP  
 WEB BROWSER  
 PRINT SCREEN  
 SELECT ALL  
 WINDOWS LOCK  
 CALCULATOR  
 DISABLE



7.




8.



•clever you

**Trust.**

VOXX  
**USER GUIDE**  
 Wireless ergonomic mouse




**FAQ**

[WWW.TRUST.COM/23731/FAQ](http://WWW.TRUST.COM/23731/FAQ)


Trust International BV - Laan van Barcelona 600 - 3317DD, Dordrecht, The Netherlands  
 ©2022 Trust All rights reserved.

Bedienungsanleitung | Mode d'emploi | Gebruikershandleiding | Manuale utente | Manual del usuario | Guia do utilizador | Brukerveiledning |  
 Bruksanvisning | Käyttöopas | Brugsvejledning | Instrukcja obsługi | Návod k použití | Návod na používanie | Használati útmutató | Manual de  
 utilizare | Ръководство за потребителя | Εγχειρίδιο χρήσης | Kullanicı kılavuzu | Руководство пользователя | Uporabniški priročnik | Korisnički  
 priručnik | Guia do usuário | Посібник користувача | 取扱説明書

1.




2.




3.



4.



5.



- OPTIONS**
- LEFT CLICK
  - RIGHT CLICK
  - MIDDLE CLICK
  - FORWARD
  - BACKWARD
  - FIRE KEY
  - TRIPLE CLICK
  - DPI +
  - DPI -
  - DPI LOOP

