


**Product information**

**A:** Snapshot button  
**B:** Multi purpose clamp  
**C:** Microphone

**D:** Adjustable lens ring  
**E:** Status LED  
**F:** Retractable USB cable

UK

**Installation**


- 1 (1) PC on. (2) Place CD in CD-ROM.
- 2 Install driver; Restart PC.  
Place camera; Connect USB.
- 3 Windows XP+SP2 → 4  
Windows 98SE/ME/2000/XP → 5
- 4 (1) No, not this time. (2) Next.
- 5 Follow steps on screen to finish.  
 Windows 98SE/ME installation CD might be required!

**Use webcam**

- 6 Open AmCap.
- 7 Enable Preview.
- 8 Adjust focus using lens ring until image clear.

**Snapshot**

- 9 Press snapshot button when the cam is in use with application software.  
Click 'File' and select 'Save As' to save the photograph.

**Reminder** **General usage**

- Use messenger service, like MSN, for video conference. Using link on CD-ROM to download.
- For information of MSN checks [www.msn.com](http://www.msn.com) or click on MSN tour link on CD-ROM.
- Windows 98SE/ME: After restarting the computer the 'Microsoft TV/VIDEO connection' installation may start. Follow on-screen instructions to finish (the Windows 98SE/ME installation CD-ROM might be required).
- Windows 98SE/ME: No network connection after installing Microsoft TV/VIDEO connection:
  - Click 'Control Panel – Network' and select 'Microsoft TV/VIDEO connection'.
  - Click 'Properties'.
  - Click the 'Bindings' tab.
  - Unselect 'TCP/IP -> Microsoft TV/Video Connection'. Restart the computer.
- Make sure there is sufficient light when use the web cam!
- Use soft brush to clean the lens when it's dusty!
- Snapshot works only when the cam is in use!
- The web cam cannot be used in more than one application at the time!
- If change the cam to other USB port, follow Hardware Wizard to finish!
- Read manual on CD for detailed use of AmCap.

- Click on 'Install software' from Trust installation menu on CD-ROM to install Ulead software. This software is only available in English. Use it optionally to organize and make make video and pictures. Use its Help if assistance is needed.

See [www.trust.com/14776](http://www.trust.com/14776) for up-to-date FAQs, drivers and instruction manuals. For extensive service, register at [www.trust.com/register](http://www.trust.com/register).

**Safety**

- Keep this device away from liquids, such as water.
- Do not open or repair this device.



- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at [www.trust.com/14776/ce](http://www.trust.com/14776/ce).



- If possible, dispose of the device at a recycling centre. Do not dispose of the device with the household waste.

**Warranty & copyright**

- This product has a two-year manufacturer's warranty which is effective from the date of purchase. For more information see [www.trust.com/warranty](http://www.trust.com/warranty)
- Reproduction of this manual or any part of it is prohibited without permission from Trust International B.V.