

## User's manual



Please contact your dealer if anything is missing or damaged.

**Warning:** *This apparatus is not suitable for children younger than 3 years old.*

The memory card has 120 blocks which are divided into 8 banks where you can save your scores and replays from your games.

### Connection

**Note:** *Do not remove the card if the game warns you not to do so. Any information saved on the card can be lost.*

Insert the card into one of the card connections at the front of your PlayStation so that the logo is facing upwards. Push it firmly into the connection.



### Use of the memory card

#### Choosing a game bank:

- Press <SELECT> on your game pad and keep it depressed.
- Press <L1> for the next bank.
- Press <R1> for the previous bank.
- Release all the buttons to select the game bank.

#### Deleting the entire card:

**Note:** *All the information stored on the card will be deleted!*

- Press <D pad>.
- Press <START> + <L2> + <R2> at the same time. An "E" will now appear six times on the display.

## Trust Memory Card 8MB PSX

---

- Release all of the buttons. All of the information stored on the card will now be deleted.

### Memory full:

If "F" appears in the display when saving information, this means that the memory is full. You will have to free some memory before saving any more information.

### Troubleshooting

| Problem                                      | Cause                                                     | Possible solution                                            |
|----------------------------------------------|-----------------------------------------------------------|--------------------------------------------------------------|
| Nothing can be saved.                        | The card is not pushed firmly enough into the connection. | Push the card firmly into the connection.                    |
|                                              | Information saved on the card is damaged.                 | Remove all the information from the card and start again.    |
| Error message or "F" appears in the display. | The card is full.                                         | Choose a different bank or remove some or all of the memory. |

Check the FAQ's on Internet at ([www.trust.com](http://www.trust.com)). You can register your product at [www.trust.com](http://www.trust.com). This will allow us to keep you informed of new products and any additions to your product.

If you still have any problems after trying these solutions, please contact your dealer or call the Trust Helpdesk. Please have the following information available:

- The article number. This is 11810.
- The game used.
- A good description of what does not work and when it happens.