

GB

TRUST ENERGY PROTECTOR 350
Instruction Manual

Version 1.0

Thank you

Thank you very much for purchasing this product from the Trust range. We wish you hours of fun with it. Please read this manual carefully before using the product.

Registration

Register your purchase via our Internet site www.trust.com, so that you are able to receive optimal guarantee and service support. You will be automatically informed of developments to your product and of other Trust products. You will also have the chance to win some spectacular prizes.

Copyright statement

No part of this instruction manual may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's own personal use, without prior written permission from the manufacturer.

Disclaimer statement

The manufacturer specifically disclaims all warranties, either express or implied, including, but not limited to, implied warranties for the marketability and suitability for a particular purpose, with respect to the software, the accompanying product manual(s) and written material, and all other accompanying hardware. The manufacturer reserves the right to revise or make improvements to its product at any time and without obligation to notify any person of such revisions or improvements.

In no event shall the manufacturer be liable for any consequential or incidental damages, including any loss of business profits or any other commercial damages, arising out of the use of its products.

All company or product names are trademarks or registered trademarks of their respective owners.

Contents

1. Introduction	4
1.1 Contents of the package	4
1.2 Minimum system requirements.....	4
1.3 Functionality of the Energy Protector 350.....	4
2. Safety	4
2.1 General information	4
3. Connections	5
4. Use	6
4.1 LED indicator	6
4.2 Charging the battery	7
4.3 The UPS when not in use	7
5. Maintenance	7
6. Technical specifications	7
7. Troubleshooting	8



1. Introduction

This instruction manual is intended for users of the Trust Energy Protector 350 (UPS). Prior knowledge of computers is not necessary to install this product. If you have any questions, please contact one of the Trust Customer Care Centers. You can find more information at the back of this instruction manual.

Note: *Turn off the computer before connecting the device.*

1.1 Contents of the package

Check the contents of the package. It should contain the following:

- Energy Protector 350 (UPS)
- Wound power cable (x2).
- This instruction manual

If anything is missing or damaged, please contact one of the Trust Care Centers. You can find more information at the back of this instruction manual.

1.2 Minimum system requirements

The Trust Energy Protector 350 (UPS) can be used with every computer, as well as with other electrical equipment.

1.3 Functionality of the Energy Protector 350

The Energy Protector protects your electrical equipment against faults in the mains voltage, such as peak voltages and drops in voltage, voltages that are permanently too high or too low (varying from 75% to 125%), contamination of the mains supply or even the total loss of power.

2. Safety

2.1 General information

Please read the following instructions carefully:

1. Disconnect the power plug from the mains supply before cleaning the device. Do not use a liquid cleaner or a spray. Clean the device with a damp cloth.
2. Do not use the device in damp environments, such as bathrooms, damp basements, swimming pools, etc.
3. Make sure the UPS is placed on firm ground, for example on the floor or on your desk.
4. Make sure nothing is placed on the power cable. Do not place the device in an area where the lead can become worn or damaged by walking on it.
5. Never stick anything into the slots on the outside of the device. You may touch live components. This may cause a fire or give you an electric shock.

6. Do not try to repair this device yourself. When you open or remove the casing, you may accidentally touch live components. There are also other risks. This device must only be repaired by specially qualified technicians.
7. The outputs on the device carry a high charge, even when it is turned off.
8. Only replace blown fuses with a fuse of the same type and value. This will prevent damage.
9. If any of the following circumstances occur, remove the plug from the power socket and have the device repaired by qualified personnel:
 - The cable or plug is damaged or worn.
 - Liquid has entered the device.
 - The device has come into contact with rain or water.
 - The device has fallen and/or the casing is damaged.
 - The performance of the device is clearly becoming worse.



Battery:

Only have the battery replaced by qualified personnel.

The battery must not be opened or damaged. Electrolyte may be released. This is harmful to skin, eyes and the environment.

Do not expose the battery to an open fire. This may cause an explosion.

Remember once the UPS reaches the end of its life span after having been used for a long time, it contains a lead battery that is filled with chemical acid. Ask your local authority where you can dispose of the UPS so that the battery and other components will be processed correctly.

Warning: *Ensure that the UPS is not over loaded. Pay attention to the maximum capacity that can be connected (300VA), as well as to the capacity of the devices to be connected.*

3. Connections

Note: *Turn your computer off before connecting the device.*

Note: *Do not connect a laser printer to the current outputs for electrical equipment (3) because these require too much power.*




Figure 1: UPS connections

1	On / Off switch
2	Current input for mains supply
3	Current output for electrical equipment
4	Telephone/modem connection (OUT)
5	Telephone/Modem connection (IN)
6	Fuse holder

1. Connect your electrical equipment to the UPS current output (3).
2. Connect the power cable (not supplied) to the UPS current input (2).
3. Insert the power cable into the power socket.
4. Turn the UPS on using the On / Off switch (1).

The Trust Energy Protector 350 can also protect your telephone and modem against peak voltages in the telephone network.

1. Connect the Telephone/modem connection IN (4) to the telephone wall outlet (cable not supplied).
2. Connect the telephone/modem cable for your telephone or modem to the UPS telephone/modem connection OUT (5).

4. Use

4.1 LED indicator

- LED indicator OFF:
UPS is switched off.
- LED indicator ON:
This LED is lit if there is sufficient mains voltage and the battery is charged up.



- LED indicator flashes and a bleeping noise can be heard:
The LED flashes if there is no longer any mains voltage and your electrical equipment is being powered by the UPS.

4.2 Charging the battery

The UPS charges the battery as soon as the plug is inserted into a wall socket. Charge the battery for 10 hours before using the functions available with the UPS.

4.3 The UPS when not in use

When the UPS has not been used for a longer period of time, the batteries should be charged for 12 hours. Repeat this procedure every 3 months. This guarantees the full capacity of the UPS for the next time it is used.

Ensure that the UPS is no longer turned on using the ON/OFF button (1) after it has been disconnected so as not to reduce the life span of the battery.

5. Maintenance

This device has been designed so that you can enjoy years of carefree use. You, therefore, do not have to spend too much time on maintenance work. Please give attention to the following points:

- Turn the UPS off before cleaning it.
- Do not use liquid cleaning materials or a spray. Clean the outside using a damp cloth.
- Regularly remove dust that collects near the ventilation openings.
- Read chapter 2 for information regarding safety.

Advice: *In order to enjoy the full capacity of your UPS, we advise you to fully unload the UPS once a year and charge it up again.*

6. Technical specifications

Input voltage	220/230/240 VAC +/- 25%
Frequency	50 / 60 Hz +/- 5%
Output voltage [VA]	300
Type of battery	Lead-acid maintenance free
Battery capacity	5 Ah
Charging time	8 hours
Peak current protection [kJ]	90
RFI filter	Yes
Number of outputs	2

7. Troubleshooting

Problem	Possible cause	Solution
LED indicator does not light up.	The On / Off button has not been pressed.	Press the On / Off button.
	The battery voltage is too low.	Recharge the UPS.
	The fuse has blown.	Replace the fuse by one of the same type (250 V, 5A).
The indicator LED flashes and a bleeping noise is heard. (UPS is in the battery mode)	The power cable has come loose.	Connect the power cable.
	The mains voltage is too high, too low or there is a power cut.	This is normal. Contact your electricity company if this lasts for a long time.
The back-up time is too short.	The battery has not been fully charged.	Recharge the UPS.

If you still have any problems after trying these solutions, please contact one of the Trust Customer Care Centers. You can find more information at the back of this instruction manual. Please have the following information available:

- The article number. This is 11943.