

TRUST AMI MOUSE OPTICAL 200

Instruction Manual

Version 1.0

Thank you

Thank you very much for purchasing this product from the Trust range. We wish you hours of fun with it. Please read this manual carefully before using the product.

Registration

Register your purchase at our Internet site, www.trust.com, so that you can receive optimal guarantee and service support. You will be automatically informed of developments to your product and other Trust products. You will also have the chance of winning some spectacular prizes.

Copyright statement

No part of this instruction manual may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's own personal use, without prior written permission from the manufacturer.

Disclaimer statement

The manufacturer specifically disclaims all warranties, either expressed or implied, including, but not limited to, implied warranties for the marketability and suitability for a particular purpose, with respect to the software, the accompanying product manual(s) and written material, and all other accompanying hardware. The manufacturer reserves the right to revise or make improvements to its product at any time and without obligation to notify any person of such revisions or improvements.

In no event shall the manufacturer be liable for any consequential or incidental damages, including any loss of business profits or any other commercial damages, arising out of the use of its products.

All company or product names are trademarks or registered trademarks of their respective owners.

Contents

1. Introduction	2
1.1 Conventions used in the manual	2
1.2 Contents of the box.....	2
1.3 Minimum system requirements	2
2. Safety.....	3
3. Connecting.....	3
3.1 Connecting the mouse.....	3
4. Use.....	4
5. Installation	4
5.1 Trust Software Installer	4
5.2 Installing the mouse software.....	5
6. Trust Ami Mouse Optical 200.....	6
6.1 'Buttons' tab	6
6.2 'Motion' tab	7
6.3 'Wheel' tab	7
6.4 'Settings' tab.....	8
6.4.1 Programming Netjump and Luckyjump	8
6.4.2 Making command lists.....	8
7. Maintenance	12
8. Removing the driver	12
9. Troubleshooting.....	13
10. Specifications	13
11. Trust Customer Care Centers	14

1. Introduction

This instruction manual is intended for users of the Trust Ami Mouse Optical 200. The mouse can be used to scroll in all your favourite applications and the buttons can be programmed for optimal use. No prior knowledge of computers is necessary to install and use this product.

If you have any questions after reading this instruction manual, please contact one of the Trust Customer Care Centers. You can find information about your nearest Customer Care Center at the back of this instruction manual. You can also visit the Trust website (www.trust.com) for support, detailed product information, drivers and FAQ's (Frequently Asked Questions).

1.1 Conventions used in the manual

The following conventions have been used in this manual to indicate instructions:

<key>	Here you should press a key. The name of the key is given between brackets.
'System'	This is a specific term used in a program. These are the terms used by, for example, Microsoft Windows 98.
[DIR]	Key in the text shown in square brackets [....].
(term)	The text between the parentheses {...} is the English term, e.g. (File) used in the figure referred to.

Additional information will be shown as follows:

Note: *This function will only work if an Internet Browser has been installed.*

The examples assume that the letter "D" has been assigned to your CD-ROM drive. If your system uses a different letter for your CD-ROM drive, for example "E", you should replace "D" by "E".

1.2 Contents of the box

Check the contents of the box. It should contain the following:

- Trust Ami Mouse Optical 200
- CD-ROM containing the drivers and instruction manuals
- Quick installation manual

Please contact one of the Trust Customer Care Centers if anything is missing or damaged.

1.3 Minimum system requirements

- 486 DX CPU
- Windows 95
- 16 MB RAM
- 10 MB free hard disk space
- 4 speed CD-ROM
- Free PS/2 mouse port

2. Safety

1. Do not use this device in a damp environment, such as a bathroom, damp basement, swimming pool, etc.
2. Do not try to repair this device yourself.
3. Under the following circumstances, remove the plug from your computer's PS/2 port and have the device repaired by qualified personnel:
 - a) The wire or the PS/2 plug is damaged or worn.
 - b) Liquid has entered the device.
 - c) The device has fallen and/or the casing is damaged.
4. Position the device so that the cable cannot be damaged.

3. Connecting

Note: *The drivers and/or software for your old mouse must be removed before installing the Trust Ami Mouse Optical 200. If available, use this software's 'Uninstall' option.*

3.1 Connecting the mouse

1. Turn off your computer and all the peripheral devices.
2. Remove the old mouse from your computer.
3. Connect the Trust Ami Mouse Optical 200 to the PS/2 port on your computer (see figure 1).




Figure 1: Connecting the mouse to your computer's PS/2 port

4. Next, turn on the computer and all the peripheral devices.

4. Use




Figure 2: Position of the buttons

Button	Function	Comment
A	Left mouse button	
B	Right mouse button	
C	Scroll wheel + third mouse button	Scrolls vertically Press the wheel to use the third mouse button
D	Scroll wheel	Scrolls horizontally
E	4 th mouse button	Programmable
F	5 th mouse button	Programmable

Table 1: Explanation of figure 2

5. Installation

Close all programs before installing the driver.

5.1 Trust Software Installer

Follow the points given below to start the Trust Software Installer.

1. Turn on your computer and start Windows.
If you are using Windows NT or Windows 2000, log in as 'Administrator'.
2. Insert the CD-ROM into your CD-ROM drive.
3. Select 'Run' from the Start menu.
4. In the command line, type [D:\SETUP.EXE] and click on 'OK'.




Figure 3: Trust Software Installer

5. Select the language you wish to use. (This language will only be used in this program.)




Figure 4: Trust Software Installer

6. Make your choice.

5.2 Installing the mouse software

1. Start the Trust Software Installer (see chapter 5.1).
2. Select the 'Install Trust Ami Mouse Optical 200' option (see figure 4).
3. Select the language you wish to have the software installed in and click on 'Next'. A new window will appear.
4. Click on 'Next' again. Figure 5 will appear.




Figure 5: Specifying the driver location

5. Click on 'Next' to accept the driver location. A new window will appear. Click on 'Change' if you wish to specify a different location and type the new location.
6. Click on 'Next'. A number of files will be copied to your computer. When completed, figure 6 will appear.



Figure 6: Installation completed

7. Select the option to restart your computer and then click on 'Finish'. The driver has now been successfully installed.

6. Trust Ami Mouse Optical 200

Note: *Some of the tabs in the mouse properties window may not be present or may be different. This is due to the number of different operating systems in use. These are Windows tabs which have no influence on the driver.*

6.1 'Buttons' tab

The mouse buttons must be set using the installed software. This is carried out as follows:

1. Double-click on the Trust icon in your taskbar (figure 7) to see the mouse properties. Figure 8 will appear.



Figure 7: Taskbar icon




Figure 8: 'Buttons' tab

2. Select the button you wish to program by clicking on the text next to the button number.
3. From the list, select the function that you wish to assign to the mouse button. The buttons will be set and be ready for use after clicking on the 'Apply' button.

Comment: *Mouse button 1 is the main button and can, therefore, not be programmed.*

6.2 'Motion' tab

There are 4 options in the 'Motion' tab (see figure 9).

1	Cursor Speed	Sets the speed of the mouse cursor.
2	SnapTo Button	Sets the cursor so that it automatically jumps to a 'highlighted' button as soon as it appears.
3	Sonar	The location of the mouse cursor will be made visible when the CTRL key on the keyboard is pressed.
4	Trails	The track of the mouse cursor is made visible as soon as it is moved.




Figure 9: 'Motion' tab

6.3 'Wheel' tab

Click on the 'Wheel' tab. Figure 10 will appear. The 'Wheel' functions can be set in this tab.




Figure 10: 'Wheel' tab

Explanation of the functions:

- **Enhanced Dual Wheel function mode**
All the functions of the MS IntelliMouse plus vertical and horizontal scrolling in Windows 95, 98, ME, 2000 and NT programs.
- **MS-IntelliMouse Compatible mode**

Only the left mouse wheel works and has the same functions as the MS IntelliMouse.

- **Swap Vertical and Horizontal Wheel**
Swaps the functions of the vertical and horizontal wheel.
- **Reverse vertical/horizontal scrolling direction**
Changes the direction of rotation.
- **Scroll x lines a time**
Sets the scrolling speed.
- **Scroll one page per scroll unit**
Moves one whole page when turning the wheel.
- **Wheel Zoom for Office 97/2000 without pressing [CTRL] key**
Use the wheel to zoom in when using Office 97/2000.

6.4 'Settings' tab

You can program the 'Netjump' and the 'Luckyjump' in this tab. These two functions can be selected in the 'Buttons' tab (see chapter 5.1).

6.4.1 Programming Netjump and Luckyjump

1. Select the function you wish to program from the 'Command List' on the left-hand side (see figure 11).




Figure 11: 'Settings' tab

2. Next, select the button you wish to assign to the chosen function from the right-hand side. The top 14 buttons are the 'Netjump' and the bottom 14 buttons are the 'Luckyjump'. When finished, click the 'Apply' button to confirm all your selections.

6.4.2 Making command lists.

It is also possible to make your own command lists. This is carried out as follows:

1. Click on the 'New/Update...' button in the 'Settings' tab. A window containing information about how to make a command menu will appear.
2. Click on the 'Add' button. Figure 12 will appear.




Figure 12: Add menu

3. Give your command list a name. We have called it 'Trust test' in the example.
4. Select an icon for the command list by clicking on 'Select Icon', selecting an icon and then clicking on 'OK'. Next, click on 'OK' in figure 12. Figure 13 will appear.




Figure 13: User options

5. Next, select an option from the list given on the right-hand side. The following options can be selected.

6.4.2.1 Application/Document

This is used to start a selected application or document.

1. Click once on 'Application/Document' and then click on '<Add New Command'. Figure 14 will appear.




Figure 14: Application/document

2. Click on 'Browse' and scroll to the application or document you wish to open.
3. If you wish, you can change the icon by clicking on 'Select Icon', selecting an icon and clicking on 'OK'.
4. Click on 'OK' to confirm your selection. The application or document you have chosen will be shown in the list in figure 13.

6.4.2.2 File Folder

This is used to open a selected folder.

1. Click once on 'File Folder' and then click on '<Add New Command'. Figure 15 will appear.




Figure 15: File Folder

2. Click on 'Browse' and scroll to the folder you wish to open.

3. If you wish, you can change the icon by clicking on 'Select Icon', selecting an icon and clicking on 'OK'.
4. For 'Mode', select 'Open' or 'Explorer'. If you select 'Open', the folder you have chosen will be opened in a new window. If you select 'Explorer', the folder you have chosen will be opened in Windows Explorer.
5. Click on 'Show Maximized' if you wish the folder to be opened in a maximized window. Leave this blank if you wish the folder to be opened in a normal window.
6. Click on 'OK' to confirm your selection. The folder you have chosen will be shown in the list in figure 13.

6.4.2.3 Home Page

This is used to open a selected Internet webpage.

1. Click once on 'Home Page' and then click on '<Add New Command'. Figure 16 will appear.




Figure 16: Home page

2. For 'URL Address', type the address of the page to be opened.
3. If you wish, you can change the icon by clicking on 'Select Icon', selecting an icon and clicking on 'OK'.
4. Click on 'Show Maximized' if you wish the web address to be opened in a maximized window. Leave this blank if you wish the web address to be opened in a normal window.
5. Click on 'OK' to confirm your selection. The web address you have chosen will be shown in the list in figure 13.

Note: This function will only work if an Internet Browser has been installed.

6.4.2.4 Mail To

This is used to write an e-mail to a selected e-mail address.

1. Click once on 'Mail To' and then click on '<Add New Command'. Figure 17 will appear.




Figure 17: Mail To

2. For 'Mail To', type the e-mail address you wish to send the e-mail to.
3. If you wish, you can change the icon by clicking on 'Select Icon', selecting an icon and clicking on 'OK'.
4. Click on 'Show Maximized' if you wish the e-mail to be shown in a maximized window. Leave this blank if you wish the e-mail to be shown in a normal window.

- Click on 'OK' to confirm your selection. The e-mail address you have chosen will be shown in the list in figure 13.

Note: This function will only work if an e-mail program has been installed.

6.4.2.5 Keyboard Sequence

This is used to program a keyboard sequence.

- Click once on 'Keyboard Sequence' and then click on '<Add New Command'. Figure 18 will appear.




Figure 18: Keyboard Sequence

- The Mode you wish to use must now be chosen. Select the 'Text' mode if only a piece of text must be placed on the screen without any commands. Select 'Keyboard Sequence' if a piece of text, which includes codes such as 'Enter', must be placed on the screen.
- For 'Keyboard Input', type the text that must be displayed on the screen. The 'Record' button must be clicked first if you have chosen the 'Keyboard Sequence' Mode. Type the sequence and then click on the 'Stop' button.
- If you wish, you can change the icon by clicking on 'Select Icon', selecting an icon and clicking on 'OK'.
- Click on 'OK' to confirm your selection. The keyboard sequence you have chosen will be shown in the list in figure 13.

6.4.2.6 Generic Command

This is used to select a standard Windows command.

- Click once on 'Generic Command' and then click on '<Add New Command'. Figure 19 will appear.




Figure 19: Generic Command

- Next, select a Windows command from the list and click on 'OK'. The command you have chosen will be shown in the list in figure 13.



6.4.2.7 '<Insert Separator' button

There is also an '<Insert Separator' button in the window shown by figure 13.

After you have made a command list, it is then possible to insert horizontal lines in the list. This can be used to separate different components from each other and to arrange the list more conveniently.

This is done as follows:

1. Use the mouse to click on the command list you have made (figure 13, middle list) and select the position where you wish to add the 'Separator Line'.
The line will be added above the selected command.
2. Click on the '<Insert Separator' button. A horizontal line will be added to the list.

6.4.2.8 Move commands

It is also possible to move commands and separator lines in the command list you have made.

1. Click on the command or separator line you wish to move. A blue bar will be visible.
2. Next, click on the 'Arrow Up' or 'Arrow Down' button to move the command in the list.
3. Click on 'OK' to confirm your choice.

7. Maintenance

The mouse does not have any moving parts and, therefore, does not require any special maintenance.

Keep the lens free of dust. Clean the lens using a clean, lint free cloth.

Note: *Never place the mouse in water or another liquid.*

8. Removing the driver

It is only necessary to remove the driver if you no longer wish to use the mouse. Follow the procedure given below:

1. Turn on the computer.
2. Close the mouse program in your taskbar.
 - a) Right-click on the icon (figure 7).
 - b) Select 'Exit' from the menu.
 - c) Select 'Yes' to close the program.
3. Click on the 'Start' button.
4. Click on 'Settings'.
5. Click on 'Control Panel'.
6. Click on the 'Add/Remove Programs' icon.
7. Select 'Trust Ami Mouse Optical 200'.
8. Click on the 'Add/Remove' button.
9. Next, click on 'Uninstall'.

The driver will be removed. Click on 'Yes' if your computer must be restarted.

9. Troubleshooting

Problem	Cause	Possible solution
The mouse does not move or moves erratically.	The surface is too smooth/slippery, e.g. glass.	Use a different surface to move the mouse over.
Windows gives an error message when starting.	The mouse has not been connected correctly.	Connect the mouse correctly (see chapter 3.1).
The scroll function does not work.	The software for your previous mouse is still active.	Remove the software for your previous mouse before installing this software. Read the instruction manual for your previous mouse to do this.
	The software has not been installed.	Install the mouse software (see chapter 5).
	The software has been installed incorrectly.	Install the software correctly (see chapter 6.3).
	The application is not 100% compatible with Windows.	Use an application that is compatible.

Check the FAQ's on the Internet (www.trust.com).

You can also register your product at www.trust.com. You will be informed of new products and of any additions to your product.

If you still have problems after trying these solutions, please contact one of the Trust Customer Care Centers.

Please have the following information available:

- The article number of this product: **12109.**
- Your hardware information.
- A good description of what exactly does not work.
- A good description of when the problem takes place.

10. Specifications

Number of buttons	5
Wheel	Horizontal and vertical wheel for scroll functions
Resolution	520 dpi
Connection	Suitable for connecting to the PS/2 port
Technology used	Special optical module, which requires no moving parts

11. Trust Customer Care Centers

Inhabitants of Great Britain and Ireland should contact:	
	Great Britain Office
From:	Internet www.trust.com
9:30 a.m. -	E-mail support-uk@trust.com
17:00 p.m.	Fax +44-(0)1376-514633
	Tel. +44-(0)1376-500000
Inhabitants of Italy should contact:	
	Italian Office
From:	Internet www.trust.com
9:00 a.m.-	E-mail support-it@trust.com
13:00 p.m. /	Fax 051-6635843
14:00 p.m. -	Tel. 051-6635947
18:00 p.m.	
Inhabitants of France and North Africa should contact:	
	French Office
From:	Internet www.trust.com
9:00 a.m. -	E-mail support-fr@trust.com
17:00 p.m.	Fax +33-(0)1-48174918
	Tel. +33-(0)1-48174931
Inhabitants of Germany should contact:	
	German Office
From:	Internet www.trust.com
9:00 a.m. -	E-mail support-de@trust.com
17:00 p.m.	Fax 02821-58873
	Tel. 0800-00TRUST (=0800-0087878)
Inhabitants of Spain should contact:	
	Spanish Office
From:	Internet www.trust.com
9:00 a.m. -	E-mail support-es@trust.com
17:00 p.m.	Fax +31-78-6543299
	Tel. +31-78-6549999
Inhabitants of the Netherlands should contact:	
	Dutch Office
From:	Internet www.trust.com
9:00 a.m. -	E-mail support-nl@trust.com
17:00 p.m.	Fax 078-6543299
	Tel. 0800-BELTRUST (=0800-23587878) or 078-6549999
Inhabitants of all other European countries should contact:	
	European Head Office
From:	Internet www.trust.com
9.00 a.m. -	E-mail support@trust.com
17.00 p.m.	Fax +31-78-6543299
	Tel. +31-78-6549999